


**Switch
Housing**

**4-SPEED © OPTIONAL
Pull Chain Operation**



Pull-chain switches on the fan control the fan and lights.

Using the fan control pull-chain switch:

- First Pull:** fan ON, High speed
- Second pull:** Medium speed
- Third pull:** Medium Low speed
- Fourth Pull:** Low speed
- Fifth pull:** Fan Off

Using the optional light pull-chain switch:
Light off at start.

- First pull:** Light ON
- Second pull:** Light OFF

Direction of blade rotation is controlled by the reverse slide switch on the side of the switch housing.

No changes in household wiring are required.